

To set LEARN on SKYTECH remote

Turn receiver to remote position.

Press in learn button and hold until it beeps.

Press ON button on the transmitter and hold.

Receiver should beep 3-4 times.

Notes:

A receiver can hold up to 3 codes from different transmitters (only 1 can be a thermostat style).

If receiver won't accept code it may be full and has to be reset/cleared. To do this hold the learn button in for 12-15 seconds and it will clear all codes from memory, then you can go into learn procedure above for new transmitter.